



ESPLOSO
Atomizzatore
3WF-14B

MIST DUSTER 3WF-14B(1)



NO.	Part No.	Part Name	Qty.	NO.	Part No.	Part Name	Qty.	NO.	Part No.	Part Name	Qty.
1	GB/T70.1+GB93+GB97	SCREW M5X18	4	23	GB93 8	WASHER	1	45	1E44F-E-PBJ.7	Admitting Pipe	1
2	1E40FP-3Z.4-1	CASE	1	24	改为3WF-14B-7	LONG NUT	1	46	GB70.1 5*25	Screw	2
3	1E40FP-3Z.4-7	SPRING	1	25	1E44F-2A.2-3	Bearing	1	47	EB-500-E.1-5	Gasket	1
4	1E40FP-3Z.4-6	PULLEY	1	26	GB1099	Key 3x5x13	1	48	1E48FP-E.4	Carburetor	1
5	1E40FP-3Z.4-9	ROPE	1	27	GB119	销 4h8×10	1	49	EB-500-E.1.6.1	Cleaner inside cover	1
6	1E40FP-3Z.4-8	START WHEEL	1	28	P40.6-4	Ring	2	50	GB70.1+GB93+GB97	Screw M5×55	2
7	GB860 8	WASHER	1	29	1E44F-2A.2-2	Piston Pin	1	51	EB-500-E.1.6-3	Filter Net	1
8	1E40FP-3Z.4-5	GUIDE SLICE	1	30	1E44F-E.3-1	Piston	1	52	EB-500-E.1.6-1	Cleaner Outside Cover	1
9	1E40FP-3Z.4-4	WASHER	1	31	1E44F-2A.2-4	Piston Ring	1	53	1E34F.1.2	Screw	2
10	GB67 M5X12	SCREW	1	32	1E44F-2A.2-4	Piston Ring	1	54	1E46FP.1.1	IGNITION COIL COMP.	1
11	GB6170 M8	NUT	1	33	1E40F-5-6	Gasket	1	55	GB/T9074.13 M4X20	BOLT	2
12	3WF-960.1-2	RATCHET	1	34	EB-500-E.1-2	Cylinder	1	56	GB/T9074.4 M5X20	BOLT	1
13	1E36F.2	Oil-seal	2	35	GB70.1	Screw M5X20	4	57	1E46FP-2	SHIELD	1
14	1E40F-E.6-2	Crank Case	1	36	EB-500-E.1-1	Mantle	1	58	GB70.1	Screw M5×30	4
15	1E40F-5.8-4	Gasket	1	37	RCJ6Y	Spark Plug	1	59	P40-5	Washer	2
16	GB/T276	Bearing 6202/P6	1	38	1E46FP.1-1	Plug Cap Ass.	1	60	EB-500-E.1-6	Parking	1
17	EB-500-E.1.2.1	Crank Shaft	1	39	EB-500-E.1-4	Gasket	1	61	P40.1-3	Baffle	1
18	GB/T276	Bearing 6202/P6	1	40	EB-500-E.1.1	Muffler	1	62	1E40FP-3Z.4-10	COVER	1
19	EB-500-E.1.3-1	Crank Case	1	41	GB/T70.1+GB93+GB97	Screw M5×12	1	63	1E40FP-3Z.4-3	COVER	1
20	1E40F-5.9	Oil-seal	1	42	EB-500-E.1-3	Muffler Shield	2	64	1E40FP-3Z.4-2	HANDLE	1
21	1E46FP.1.1	Fly Wheel	1	43	GB70.1+GB97	Screw M6×60-12.9	2				
22	GB96 8	WASHER	1	44	1E40F-5-2	Gasket	2				

MIST DUSTER 3WF-14B(2)



Ser.No.	Part No.	Part Name	Qty	Ser.No.	Part No.	Part Name	Qty	Ser.No.	Part No.	Part Name	Qty	Ser.No.	Part No.	Part Name	Qty	Ser.No.	Part No.	Part Name	Qty	Ser.No.	Part No.	Part Name	Qty
57	3WF-20.9-2	M5*16 自攻螺丝	4	79	3WF-14-7	frame	1	101	3W-16.4-2	connector	1	123	3WF-2.6.4-4	tube	1	145	3WF-14.5.1-1	handgrip	1	167	GB894.1 10	RING	1
58	3WF-14-6	protection	1	80	EB-650-10	axis	2	102	3W-16.4-3	sealing washer	1	124	3WF-2.6.4-3	tube	1	146	3WF-14.5.1-10	handgrip	1	168	3WF-3S.3.1-10	board	1
59	GB/T96	washer 6	2	81	EB-650.10	gallus	2	103	3WF-16.4-1	connector lid	1	125	3WF-3.19.3-3	valve	1	147	3WF-14.5.1-9	Screw	1	169	HG4-338 10X19X5	RING	1
60	GB/T6177	Nut M6	2	82	3WF-14.7	mat	1	104	JB/T8870	hoopØ25-Ø40	3	126	GB1235 16×2.4	sealing washer	1	148	3WF-14.5.1-5	switch	1	170	GB818 M3X10	SCREW	1
61	GB70+GB93+GB97	SCREW M6 × 30	6	83	3WF-2.6B-2	plastic clip	5	105	3WF-14B-5	connector	1	127	3WF-2.6.4.3-1	nozzle	1	149	3WF-14.5.1-4	patch	1	171	GB96 3	WASHER	1
62	GB/T818	SCREW M5 × 70	2	84	GB/T9074.4 M6×12	M6×12 Screw	2	106	3WF-16.2-1	tube	1	128	3WF-2.6.4.3.1.1	nozzle	1	150	3WF-3.19.1-1	core	1	172	3WF-3S.3.1-6	ABASE	1
63	GB/T6170	M5 Nut	2	85	EB-500-E.4-1	gasoline tank	1	107	3WF-3-3	clip	改为2	129	3WF-2.6.4.3.1-1	washer	1	151	3WF-14.5.1.2-1	seat	1	173	3WF-3S.3.1-8	IMPELLER	1
64	EB-500-E.2-1	volute case	1	86	1E34F.9.2-3D	filter	1	108	3WF-950.2.1-2	loop	1	130	3WF-2.6.4.3.1-3	rotation impeller	1	152	3WF-3.19.1-2	shell	1	174	GBT6170 M6	NUT	1
65	EB-500-E.2-3	impeller	1	87	EB-415.4.2-2	stopper	1	109	3WF-950.2.1-1	connector lid	1	131	3WF-2.6.4.3.1-2	seat	1	153	GB/T 845	ST4. 2X8 Screw	2	175	3WF-3S.3.1-9	AUPSIDE	1
66	GB70+GB93+GB97	M5X35(10.9) Screw	4	88	EB-415.4.2-4	tube(100mm)	1	110	3WF-16.2-3	tube	1	132	3WF-2.6.4.3.1	nozzle	1	154	GB/T828	M3X5X2. 5 screw	1	176	GB818 M4X16	SCREW	1
67	EB-500-E.2-2	volute case	1	89	CG420.1.3.2-2	tube(270mm)	1	111	GB/T13527.1 10×1.5×830	tube	1	133			155	GB/T845	ST4. 8×13 screw	1	177	GB/T818 M4*8	SCREW	1	
68	XSS46-2.2-5	M5*20 Screw	10	90	GB/T 8870	hoopØ59-Ø82	1	112	删除			134	3W-15A-3	line	1	156	3WF-3.19.1	cock assem (no board)	1	178	3WF-3.19-1	TUBE 10*2*880	3
69	GB70+GB93+GB97	M6*30 Screw	6	91	1E32FL.6.2	lid	1	113	3WF-16.3-1	plug	1	135	3WF-14B.3.1.1	line	1	157	3WZ-4.15.1	spanner	1	179	GB/T13527.1	CLIP	1
70	3WF-14-10	board	1	92	3WF-8.1-2A	lid	1	114	3WF-950.1.1-1	tube	1	136	CG328.1.1-4	tube	1	158	3WF-3.25.4	chain	1	180	QC/T621 K673B13	CLIP	4
71	3WF-14-11	board	1	93	3WF-8.1-1	sealing washer	1	115	3WF-16.3.1-3	board	1	137	GB/T 845	ST5.5*25 Screw	1	159	ZB4-10.1	OIL bottle	1	181		tube 8*2.5*150	1
72	3WF-14-9	board	2	94	3WF-14.3-1	air valve	1	116	3WF-14B1.1-1	elbow	1	138	GB/T 845	ST4.2*19 Screw	5	160				182	3WF-3S.3-1	STEM	1
73	3WF-14B-4	support	1	95	3WF-14.3-3	filter	1	117	3WF-28.6-2	cover	1	139	3WF-14.5.1-2	handgrip	1	161	3WF-3S.3.1-4	PLASTIC TIE-IN	1	183		tube 8*2.5*150	1
74	GB70+GB93+GB97	M6*16 Screw	4	96	GB/T13527.1 8×1.5×500	tube	1	118	3WF-16.3.1-2A	switch	1	140	3WF-14.5.1-7	spring	1	162	GB/T 6177	M4 nut	3	184		link	1
75	3WF-14B-3	board	3	97	3WF-14B.2-1	chemical tank	1	119	GB/T 8870	hoopØ78-Ø102	1	141	3WF-14.5.1-3	handgrip	1	163	GB/T9074.4	M4*10screw	1	185	GB/T13527.1	TUBE 10*2*880	1
76	3WF-14-12	spring	1	98	3WF-3A.1-2	sealing washer	1	120	3WF-3.19-4	tube	1	142	GB/T6172.2	M6 nut	1	164	3WF-30.3.1-7	NET COVER	1				
77	250*4. 5	line	1	99	3WF-3A.1-1	link pipe	1	121	3WF-2.6.4.1	connector	1	143	3WF-14.5.1-8	washer	1	165	3WF-3S.3.1-5	BEARING	1				
78	3F-30. 17	rubber pillar	2	100	3WF-3A.1-3	connector lid	1	122	3WF-2.6.4-2	tube	1	144	GB/T955	washer	1	166	GB276 D6000-22	spanner	1				