

CERUTI

www.ceruticenter.it


ESPLOSO

Decespugliatore


elettrico

3GC36D







Ser.NO.	Part NO	Part Name	Qty.
1	3GC36D.2-1	Left Hemi	1
2	3GC36G.3-2	Left half control box	1
3	3GC36G.2-6	Damping rubber	2
4	3GC36D.3.1-1	Rectifier diode	1
5	3GC36D.3.1	Speed regulation switch	1
6	3GC36D.3-3	Control handle	1
7	3GC36D.3-7	Left lock button	1
8	3GC36D.3-5	Reset spring	2
9	3GC36D.3-6	Limit handle	1
10	3GC36D.3-4	Right lock button	1
11	3GC36D.2-2	Right Hemi	1
12	3GC36D.3-1	Right half control box	1
13	GB/T 818	SCREW M5×20	1
14	3GC36D.2-4	SCREW M4×16	20
15	GB/T 6170	NUT M5	1
16	3GC36D.2.2	Junction plate	1
17	3GC36D.1-7	SCREW M3×16	6
18	3GC36D.1-1	Front half battery pack	1
19	3GC36D.1-3	LOCK button	1
20	3GC36D.1-5	Reset spring	1
21	3GC36D.1-4	Limit plate	1
22	3GC36D.1-6	SCREW M3×10	2
23	3GC36D.1.1	Battery combination	1
24	3GC36D.1-2	Back half battery pack	1
25	GB70.1+GB93+GB97	SCREW M5×25	1
26	GB70.1+GB93+GB97	SCREW M5×12	1
27	GB70.1	SCREW M5×14	3
28	3GC36D.2-7	Connection disk	1
29	3GC36D.2-3	Connection sleeve	1
30	3GC36D.2-5	Damping rubber	2
31	3GC36D.2.1	Motor	1
32	3GC36D.2.3	Controller	1




Ser.NO.	Part NO	Part Name	Qty.
1	CG230B.2-2	Rubber Cover	5
2	BG430F.4-4	Oil-bearing	5
3	3GC36D.4-2	Drive Shaft	1
4	3GC36D.4-1	Pipe	1



Ser.NO.	Part NO	Part Name	Qty.
1	CG245Q.11.1	Handle Cover	1
2	CG330A-E-MS-1	Rubber Cover	1
3	CG245Q.11-1	Handle	1
4	1E40F-5A-CE-4	Screw M5×30	4



Ser.NO.	Part NO	Part Name	Qty.
1	CG230B.3.1	Harness Clamp	1
2	CG230B.3.2	Clamp	1
3	GB/T70.1	Screw M5×20	1
4	GB/T889.1	Nut M5	1



Ser.NO.	Part NO	Part Name	Qty.
1	GB70.1+GB93+GB97	Screw M6×20	2
2	3GC36D.5-1	Safety Guard Bracket	1
3	GB70.1+GB93+GB97	Screw M5×14	1
4	BG430F-BS.6	Gear Case Ass'y	1
5	3GC36D.5.2	Nylon Cutter Head	1
6	GB/T70.1+GB/T93	Screw M5×20	1
7	3GC36D.5.1	Safety Guard	1
8	CG305F.11-1	BLade	1
9	XSS46-2.2-5	Screw M5×20	2