

CERUTI


www.ceruticenter.it

ESPLOSO

Irroratrice

WS-5CD





WS-5CD PARTS LIST

DESCRIPTION	PART NO.	DESCRIPTION	PART NO.
BOTTLE CAP –BLACK	3216	FEED NOZZLE, GREY	5409
AIR VENT TUBE – 0.20M	3512/20	LABEL, ULVA+	5410
WIRE, 1.00MM, BLACK -0.94M	4134/94	BUNG	5415
WIRE, 1.00MM, RED – 0.98M	4368/98	RETAINING STRAP	5451
SPRING HOLDING PIN	4447	TERMINAL RING	5575
SPRING, 9/32"	4457	NUT, M5, WING 9	601
LABEL, BATTERY ON/OFF	4460	WASHER, M5 X 25 OD X 1.5 THICK	6020
BOTTLE CAP – BLACK	4489	SCREW, M5 X 30, HEX. SET	6021
SCREW, NO. 6 X 3/8" S/T	4646	SWITCH PLUG	6042
BOTTLE, 1 LITRE (TWIN NECK)	5265	SWITCH SLEEVE	6043
MOTOR, 12 VOLT, ULVA+	5320	SWITCH CONNECTOR	6044
CORK WASHER	5353		
SPRING, BATTERY CASE	5363	REFILLING SYSTEM/ BACKPACK	
BOTTLE HOLDER	5365	TUBE, 6MM ID X 9MM OD – 1.00M, PVC	4993/100
MOTOR FRONT PLATE	5366	STRAP – 1.25M	5107/125
MOTOR HOUSING	5367	BOTTLE, 1 LITRE (REFILL SYSTEM)	5290
HEAD LOCKING SLEEVE	5368	BACKPACK, 5 LITRE	5404
NUT, UNION – BLACK	5369	TUBE, 8MM ID X 12MM OD – 0.90M, PVC	5414/90
DISC FIXING SCREW	5372	CLIP, HOSE, SIZE BB	5417
ATOMISER DISC	5373	CLIP, HOSE, NO.12, WINGSCREW	5464
CENTRE CONNECTOR	5375	TAP	5776A
BATTERY CASE END CAP	5376	HOSE CONNECTOR, 6MM	5778
BATTERY CASE	5377	UNION NUT	5779
FEED NOZZLE, YELLOW	5383	VALVE CLAMP	5780
FEED NOZZLE, ORANGE	5384	SCREW, M5 X 12, POZI, PAN, PT	5956
FEED NOZZLE, RED	5385	CLIP, HOSE, WIRE 9.1MM	6028
FEED NOZZLE, BLACK	5386	CLIP, HOSE, WIRE 11.9MM	6029
FEED NOZZLE, PINK	5387		
PROTECTIVE COVER	5396	CAP AND FILTER ASSEMBLY FOR	5404
'O' RING, BS 012, VITON	5398	CAP, BACKPACK – BLACK	5208
SCREW, NO.6 X 3/8" S/T POZI PAN/HEAD B	5399	BALL, 3/16" DIA, POLYPRPYLENE	5210
EXTENSION TUBE	5400	CORK GASKET SEAL	5346
'O' RING, BS 121, VITON	5403	AIR BLEED VALVE BODY	5448
ATOMISER WASHER	5407	FILTER (BACKPACK)	5449