


CERUTI

www.ceruticenter.it

ESPLOSO
Motopompa
QGZ25-30E




1E36F-2E 汽油机分解图



1E36F-2E 汽油机

序号	规格	名称	数量	序号	规格	名称	数量	序号	规格	名称	数量	序号	规格	名称	数量
1	1E36FE. 9-3	螺钉	1	24	1E36F-2E. 2. 1. 1	磁电机转子	1	47	L8RTC	火花塞	1	70	1E36F-E. 7-1	空滤器外罩	1
2	1E36FE. 9-4	起动轮	1	25	GB/T859	垫圈8	1	48	1E40F-3A. 8-2	火花塞卡簧	1	71	1E34F. 1. 2	大头螺钉	1
3	1E36FE. 9-1	绳轮	1	26	GB/T97. 1	垫圈8	1	49	1E34F. 5-3	火花塞罩	1	72	1E36F-E-5	油箱挂架	1
4	1E36FE. 9-5	起动拉绳	1	27	GB/T6170	螺母M8	1	50	1E34F. 5-2	高压帽	1	73	1E40F-5A-2	橡胶套	1
5	1E36FE. 9-7	起动器平簧	1	28	1E36F-2E. 2. 1. 2	磁电机定子	1	51	1E40F-5. 3-1	胶塞	1	74	P40. 12. 2-3A	燃油过滤器	1
6	1E36FE. 9-8	壳体	1	29	1E36F-2. 3. 1	停车线组	1	52	1E36F-E-4	上压盖	1	75	CG420. 1. 3. 2-2	透明塑料管3×1×145	1
7	GB70. 1+GB93+GB97	螺钉组合件M5×20	6	30	GB70. 1+GB93+GB97	螺钉组合件M5×20	6	53	1E36F-E-2	消音器垫	1	76	EB-415. 4. 2-2	油管塞	1
8	1E40FP-3Z. 4-2	起动器手柄	1	31	1E36F-3	垫圈B	2	54	HA36-2. 3	消音器	1	77	EB-415. 4. 2-4	透明塑料管2. 5×1. 25×90	1
9	1E40FP-3Z. 4-10	增强套	1	32	1E36F-E. 6B-1	拉簧	1	55	GB70. 1+GB93+GB97	螺钉组合件M5×12	1	78	GB70. 1+GB93+GB96	螺钉组合件M5×16	2
10	1E36FE. 9-6	压簧	1	33	1E36F-2C. 4. 1	涨紧块	2	56	1E33F-4	隔热垫	2	79	1E36FE. 10-1	油箱	1
11	1E36FE. 9-2	起动拨杆	2	34	1E40F-5-11	波形垫圈	2	57	GB70. 1+GB97	螺钉组合件M5×60-12. 9	2	80	1E32FL. 6. 2-4	防脱链	1
12	1E36FE. 9	起动器	1	35	P40-18	螺钉轴	2	58	1E36F-E-8	进气管垫	1	81	1E32FL. 6. 2-3	端盖	1
13	1E40F-5-10	起动器垫	1	36	1E36FE-5	磁电机罩壳	1	59	1E36F-2A-2	进气管	1	82	1E32FL. 6. 2-2	油箱内盖	1
14	1E36FE. 7	起动拨盘焊合	1	37	1E36F-2. 4. 1	小头滚针轴承	1	60	1E34F-1	化油器侧密封垫	1	83	EB-415. 4. 1. 1-1	进气嘴	1
15	1E36F. 2	小油封	2	38	1E36F. 10-2	活塞销挡圈	2	61	1E34F-2E. 1A	化油器	1	84	CG420. 1. 3. 1-2	密封垫	1
16	1E36F-E. 8-2	后半曲轴箱	1	39	1E36F-E. 4-1	活塞	1	62	1E34F. 1-2	阻风门手柄	1	85	1E32FL. 6. 2-1	油箱盖	1
17	1E36F-2. 6-3	曲轴箱密封垫	1	40	1E36F. 10-1	活塞销	1	63	1E34F. 1-7	止退塞	1	86	1E32FL. 6. 2	油箱盖组合	1
18	GB/T276	轴承 6201/P6	2	41	1E36F. 10-3	活塞环	2	64	GB/T6170	螺母 M4	1	87	1E40F-5A-3	橡胶垫	2
19	1E36F-E. 4. 1	曲轴连杆组	1	42	1E36F-E-3	缸垫	1	65	1E34F. 1. 1	空滤器内罩组合	1	88	1E36F-2E-3	隔热罩	1
20	GB/T1099	半圆键3×5×13	1	43	1E36F-2E-1	缸体	1	66	GB70. 1+GB97	螺钉组合件M5×55	2	89	GB70. 1+GB93+GB97	螺钉组合件M4×12	1
21	GB/T119. 1	销 4h8×10	4	44	GB/T70. 1	内六角螺钉M5×18	4	67	1E34F. 1-3	阻风门	1				
22	1E36F-E. 8-1	前半曲轴箱	1	45	1E36F-E. 5	缸体护罩组合	1	68	GB/T845	缸体护罩组合	1				
23	GB/T70. 1	内六角螺钉M5×30	4	46	GB70. 1+GB93+GB97	螺钉组合件M5×16	1	69	1E34F. 1-1	滤芯	1				



Appendix. list of Pump Parts

Ser.NO	Part NO	Part Name	Qty.	Ser.NO	Part NO	Part Name	Qty.
1	QGZ215-30.4-1	HOSE JOINT	2	24	QGZ40-35.10	THROTTLE LEVER	1
2	QGZ25-30.4-3	HOSE COUPLING	2	25	GB 97.1	WASHER	2
3	QGZ25-30.4-2	PACKING(PLUG)	2	26	GB 93	WASHER SPRING	2
4	QGZ25-30-6	VALVE CASE	1	27	GB 889	NUT M5	1
5	QGZ25-30-2	CHECK VALVE	1	28	GB 6170	NUT M8	4
6	GB 9074.15	BOLT W/S.W M6X20	7	29	QGZ40-35A.3	RUBBER PILLAR	1
7	GB 3452.1	O-SEALING RING	2	30	GB6170	NUT M5	1
8	QGZ25-30-9	PLUG	2	31	QGZ40-35A.1	BASE	1
9	GB 9074.15	BOLT W/S.W M8X20	4	32	QGZ40-35-5	ANTI VIBRATION RUBBER	4
10	QGZ25-30-3	PUMP CASE	1	33	GB 96	WASHER	4
11	QGZ25-30-8	PACKING	1	34	GB 845	SCREW ST4.2X13	4
12	QGZ25-30-7	BEND	1				
13	GB 9074.15	BOLT W/S.W M8X30	2				
14	GB 3452.1	O-SEALING RING	1				
15	QGZ25-30-5	VOLUTE SHELL	1				
16	QGZ25-30-4	IMPELLER	1				
17	GB 3452.1	O-SEALING RING	1				
18	QGZ40-35.4	MECHANICAL SEAL	1				
19	QGZ40-35-8	SEAL PACKING	4				
20	GB 70	SCREW M6X40	4				
21	GB 3452.1	O-SEALING RING	1				
22	QGZ25-30-2	CASING COVER	1				
23	QGZ25-30-10	HANDLE	1				