

CERUTI

www.ceruticenter.it


ESPLOSO

Motore

43 CC EURO 2







NO.	Part No.	Part Name	Qty.	NO.	Part No.	Part Name	Qty.	NO.	Part No.	Part Name	Qty.	NO.	Part No.	Part Name	Qty.
1	1E36FE, 9-3	Screw	1	32	GB9074, 13	Bolt M5 × 20	2	62	1E40F-E-8	Gasket	1	66	1E34F, 1-2	Choker Handle	1
2	1E36FE, 9-4	Ratchet	1	33	1E36F-3	WasherB	2	63	1E40F-SA, 2	Admitting Pipe	1	67	1E34F, 1-7	Stop ring	1
3	1E36FE, 9-1	Starter Rope Reel	1	34	1E36F-E, 6-1	Spring	1	64	1E40F-E-7	Gasket	1	68	GB/T6170	Nut M4	1
4	1E36FE, 9-5	Starter Rope	1	35	1E40F-5, 6A-1	Expander	2	65	1E40F-E, 1A	Carburetor	1	69	1E34F, 1, 1	Cleaner inside cover	1
5	1E36FE, 9-7	Recoil Spring	1	36	1E40F-5-11	Washer	2	65-1		Thimble	1	70	GB/T9074, 4	Screw M5x50	2
6	1E36FE, 9-8	Starter Cover Ass'y	1	37	1E40F-5-12	Screw Pin	2	65-2		Main Needle	1	71	1E34F, 1-3	Choker	1
7	GB9074, 4	Screw M5 × 20	5	38	1E40F-5-9	Fan Cover	1	65-3		Screw	1	72	GB/T845	Screw ST4, 2X12	1
8	1E40FP-3Z, 4-2	Start Handle	1	39	1E40F-5, 9	Oil-seal	1	65-4	GB/T823	Screw M3 × 10	2	73	1E34F, 1-1	Filter Net	1
9	1E40FP-3Z, 4-10	Ring	1	40	GB9074, 13	Screw M5 × 25	2	65-5		Swivel	1	74	1E36F-E, 7-1	Cleaner Outside Cover	1
10	1E36FE, 9-6	Spring	1	41	1E44F-2A, 2-3	Bearing	1	65-6	GB896	Ring 3, 5	1	75	1E34F, 1, 2	Screw	1
11	1E36FE, 9-2	Start pole	2	42	1E40F-03, 02, 01	Ring	2	65-7		Turn Frame	1	76	1E36F-E-5	Stand	1
12	1E36FE, 9	Starter	1	43	1E40F-E, 4-1	Piston	1	65-8		Airproof Ring	1	77	1E40F-SA-2	Rubber Cover	1
13	1E40F-5-10	Gasket	1	44	1E46FP, 6-3	Piston Pin	1	65-9	GB/T6172	Nut M6	1	78	1E34F, 9, 2-3B	Cleaner Cover	1
14	1E36FE, 7	Start Reel	1	45	1E40FP-3Z, 3-5	Piston Ring	2	65-10		Nut, Adjuster	1	79	1E36FE, 10, 1-2	Fuel Pipe	1
15	1E36F, 2	Oil-seal	1	46	1E40F-E-3	Gasket	1	65-11		Bracket	1	80	1E36FF, 8, 1-1	Plug	1
16	1E40F-E, 6-2	Crank Case	1	47	1E40F-E-1	Cylinder	1	65-12		Fixed Board	1	81	1E36FE, 10, 1-1	Fuel Pipe	1
17	1E40F-5, 8-4	Gasket	1	48	GB/T70, 1	Screw M5 × 20	4	65-13		Spring	1	82	GB/T9074, 4	Screw M5 × 16	2
18	GB/T276	Bearing 6202/P5	2	49	1E40F-E, 5	Guide Cover Ass'y	1	65-14		Column	1	83	1E40F-IIS, 5, 1	Fuel Tank	1
19	1E40F-E, 4, 1A	Crank Shaft	1	50	L8RTC	Spark Plug	1	65-15		Ring	1	84	1E32FL, 6, 2-4	Chain	1
20	GB1099	Key 3x5x13	1	51	1E40F-3A, 8-2	Spring	1	65-16		OverBody	1	85	1E32FL, 6, 2-3	End Cover	1
21	GB119	Pin B5 × 12	2	52	1E34F, 5-3	Plug Cap	1	65-17		O Ring	1	86	1E32FL, 6, 2-2	Inside Cover	1
22	1E40F-E, 6-1	Crank Case	1	53	1E34F, 5-2	Cap	1	65-18		Pinhole	1	87	EB-415, 4, 1, 1-1	Inlet	1
23	GB9074, 4	Screw M4 × 8	1	54	1E40F-5, 3-1	Plug	1	65-19		Gasket, Pump	1	88	CG420, 1, 3, 1-2	Gasket	1
24	GB119	Pin B4 × 10	2	55	1E40F-E-4	Cover	1	65-20		Diaphragm, Pump	1	89	1E32FL, 6, 2-1	Fuel Tank Lid	1
25	GB9074, 4	Screw M5 × 30	4	55A	1E36F-2C-1	Gasket	1	65-21		Mid-body	1	90	1E32FL, 6, 2	Lid Ass'y	1
26		MAGNETO ROTOR COMP.	1	56	1E40F-E-2	Gasket	1	65-22		Gasket Diaphragm	1	91	1E40F-SA-3	Rubber washer	2
27	GB/T859	WasherB	1	57	1E40F-E, 2	Muffler	1	65-23		Diaphragm	1	92	1E40F-E-6	Stand	1
28	GB/T97, 1	WasherB	1	58	GB9074, 4	Screw M5 × 12	2	65-24		Body Purge	1	93	1E36F-2-10	Label	1
29	GB6170	Nut M8	1	59	1E40F-5-13	Bolt	2	65-25		Pump Priming	1	94	1E40F-E-6	Cover	1
30		IGNITION COIL COMP.	1	60	GB6177, 1	Nut M6	2	65-26		Cover Pump	1	95	GB9074, 13	Screw M5 × 30	2
31	1E36F-2, 3, 1	Cord Comp.	1	61	GB9074, 4	Screw M5 × 25	2	65-27	GB/T818	Screw M3 × 22	4				