

CERUTI

www.ceruticenter.it

ESPLOSO

Soffiatore

EB500-E



KASEI

Fig. 1 ENGINE GROUP

EB-500-E




Fig. 1 ENGINE GROUP

NO.	PART NUMBER	DISCREPTION	QTY.	NO.	PART NUMBER	DISCREPTION	QTY.	NO.	PART NUMBER	DISCREPTION	QTY.
1	GB9074. 4	SCREW M5 × 16	4	28	GB 1099	KEY 3 × 5 × 13	1	55	EB-500-E. 1. 6. 1	INSIDE COVER	1
2	1E40FP-3Z. 4	STARTER ASSY	1	29	1E44F-2A. 2-3	BEARING	1	56	P40. 1-3	BAFFLE	1
3	1E40FP-3Z. 4-10	. KNOB CAP	1	30	P40. 6-4	SNAP RING	2	57	GB70. 1+GB93+GB97	SCREW M5 × 55	2
4	1E40FP-3Z. 4-2	. KNOB	1	31	1E44F-2A. 2-2	PISTON PIN	1	58	EB-500-E. 1. 6-3	FILTER NET	1
5	1E40FP-3Z. 4-1	. CASE	1	32	1E44F-E. 3-1	PISTON	1	59	EB-500-E. 1. 6-1	OUTSIDE COVER	1
6	1E40FP-3Z. 4-7	. SPRING	1	33	1E44F-2A. 2-4	PISTON RING	2	60	1E34F. 1. 2	KNOB BOLT	2
7	1E40FP-3Z. 4-6	. REEL	1	34	1E40F-5-6	GASKET	1				
8	1E40FP-3Z. 4-9	. ROPE	1	35	EB-500-E. 1-2	CYLINDER	1				
9	1E40FP-3Z. 4-8	. WHEEL	1	36	GB70. 1	SCREW M5 × 20	4				
10	GB860 8	. WASHER	1	37	1E40F-5-8	GASKET	2				
11	1E40FP-3Z. 4-5	. GUIDE SLICE	1	38	EB-500-E. 1-1	MANTLE	1				
12	1E40FP-3Z. 4-4	. WASHER	1	39	RCJ6Y	SPARK PLUG	1				
13	GB67	. SCREW M5 × 12	1	40	1E46FP. 1	MAGNETO	1				
14	GB 6170	NUT M8	2	41	P40-5	WASHER	2				
15	3WF-960. 1-2	START REEL	1	42	EB-500-E. 1-6	STOP WIRE	1				
16	1E36F. 2	SEAL	1	43	GB9074. 13	SCREW M4 × 20	2				
17	1E40F-E. 6-2	BACK CANKCASE	1	44	GB9074. 4	SCREW M5 × 20	1				
18	1E40F-5. 8-4	GASKET	1	45	1E46FP-2	SHIELD	1				
19	GB/T 276	BEARING 6202/P6	2	46	EB-500-E. 1-4	GASKET	1				
20	EB-500-E. 1. 2. 1	CRANKSHAFT	1	47	EB-500-E. 1. 1	MUFFLER	1				
21	EB-500-E. 1. 3-1	FRONT CANKCASE	1	48	EB-500-E. 1-3	SHIELD	1				
22	1E40F-5. 9	SEAL	1	49	GB70. 1+GB93+GB97	SCREW M6 × 60-12. 9	2				
23	1E46FP. 1. 1-	FLYWHEEL	1	50	GB70. 1+GB93+GB97	SCREW M5 × 12	1				
24	GB/T 96. 1	WASHER 8	1	51	1E44F-E-PBJ. 7	INSULATOR	1				
25	GB/T93	WASHER 8	1	52	GB70	SCREW M5 × 25	2				
26	GB70. 1	SCREW M5 × 30	4	53	EB-500-E. 1-5	GASKET	1				
27	GB119	PIN 4h8 × 10	2	54	1E48FP-E. 4	CARBURETOR	1				

Fig. 2 BLOWER GROUP

EB-500-E




Fig. 2 BLOWER GROUP

NO.	PART NUMBER	DISCREPTION	QTY.	NO.	PART NUMBER	DISCREPTION	QTY.	NO.	PART NUMBER	DISCREPTION	QTY.
1	3WF-20.9-2	SCREW M5 × 16	4	28	P40.12.2-3A	. FILTER	1	55	BL750.3-8	. PIN	1
2	EB-500-E-4	ENGINE COVER	1	29	CG420.1.3.2-2	. FULE TUBE	270mm	56	BL750.3-2	. SPRING	1
3	GB70.1+GB93+GB97	SCREW M6 × 30	6	30	EB-415.4.2-4	. FULE TUBE	100mm	57	BL750.3-3	. LEVER	1
4	EB-500-E.2.1	VOLUTE CASE	1	31	EB-415.4.2-2	. VITTA	1	58	BL750.3-4	. LEVER, throttle	1
5	EB-500-E.2.3	IMPELLER	1	32	3W-950.4	SUPPORT	2	59	BL750.3-1	. LONG SPRING	1
6	GB70.1+GB93+GB97	SCREW M5 × 35	4	33	250 × 4.5	LINE	2	60	CG330B-3E.2.1-1	. RIGHT MANIPULATOR	1
7	EB-500-E.2.2	VOLUTE COVER	1	34	3F-30.8-2	RUBBER PLUG	1	61	GB/T 845	. SCREW ST2.9 × 18	3
8	3WF-20.9-4	SCREW M5 × 20	9	35	GB/T6170	NUT M5	3	62	GB/T 70.1	. SCREW M5 × 30	1
9	GB/T 818	SCREW M5 × 70	2	36	GB/T70.1	SCREW M5 × 10	1	63	GB/T 889	. NUT M5	1
10	EB-500-E-3	PROTECT NET	1	37	3F-30.18-1	ELBOW	1				
11	3WF-2.6B-2	CLIP	12	38	JB8870	CLAMP 78-101	1				
12	3W-11.3	DAMPER	2	39	EB-650.7-2	HOSE	1				
13	EB-500-E-2	FRAME	1	40	JB8870	CLAMP 59-82	1				
14	GB/T 96.1	WASHER 6	7	41	EB-650.7.1	SWIVEL JOINT	1				
15	GB/T 6177	NUT M6	4	42	EB-650.7-3	PIPE, STRAIGHT	1				
16	EB-500-E-1	PAD	1	43	EB-650-E.5-1	PIPE, END	1				
17	EB-500-E.3	BAND ASSY	2	44	EB-650.7.2-1A	HANDLE	1				
18	GB70+GB93	SCREW M6 × 16	2	45	GB/T 5783	BOLT M6 × 45	1				
19	EB-500-E.4	FULE TANK ASSY	1	46	GB/T 62	NUT M6	1				
20	1E32FL.6.2	. CAP ASSY	1	47	EB-500-E-CZHZZ	LEVER SET	1				
21	1E32FL.6.2-1	.. CAP	1	48	BC36.3.1	. STOP SWITCH	1				
22	CG420.1.3.1	.. WASHER	1	49	3WF-16.3.2.2	. CABLE	1				
23	EB-415.4.1.1-1	.. HOLDER	1	50	3WF-16.3.2-1	. TUBE	1				
24	1E32FL.6.2-2	.. LID	1	51	GB/T 846	. SCREW ST2.9 × 13	1				
25	1E32FL.6.2-3	.. LID	1	52	BL750.3-9	. PUSH BUTTION	1				
26	1E32FL.6.2-4	.. STOPPER	1	53	BL750.3-7	. SPRING	1				
27	EB-500-E.4-1	. FULE TANK	1	54	CG330B-3E.2.1.2	. LEFT MANIPULATOR	1				