

# **CERUTI**

**[www.ceruticenter.it](http://www.ceruticenter.it)**

**ESPLOSO**


**Soffiatore**

**EB650A-E**



***KASEI***


FIGURE 1



## (1E48FP-E) Appendix List of Attached Fig.1(1E48FP-E)

| Ser.NO. | Part NO.                   | Part Name       | Qty. | Ser.NO. | Part NO.                 | Part Name      | Qty. | Ser.NO. | Part NO.                 | Part Name       | Qty. |
|---------|----------------------------|-----------------|------|---------|--------------------------|----------------|------|---------|--------------------------|-----------------|------|
| 1-1     | GB70.1+GB93+GB97.1 M6X16   | BOLT            | 1    | 1-30    | 1E44F-2A.2-3             | BEARING        | 1    | 1-59    | 1E48FP-6                 | SEALING GASKET  | 1    |
| 1-2     | 1E48FP-E.3                 | MUFFLER         | 1    | 1-31    | 1E40F-03.02.01           | RING           | 2    | 1-60    | GB70.1+GB93+GB97.1 M5X30 | BOLT            | 2    |
| 1-3     | EB-650-E-1                 | MUFFER GASKET   | 1    | 1-32    | 1E48FP.5-2               | PISTON PIN     | 1    | 1-61    | 1E48FP-5                 | PIPE            | 1    |
| 1-4     | GB/T70.1+GB97.1 M6X75-10.9 | BOLT            | 2    | 1-33    | 1E48FP-E.1-1             | PISTON         | 1    | 1-62    | 1E48FP-4                 | GASKET          | 1    |
| 1-5     | GB70.1+GB93+GB97.1 M5X20   | BOLT            | 4    | 1-34    | 1E48FP.5-4               | PISTON RING    | 1    | 1-63    | 1E48FP-9                 | GUIDE AIR PLATE | 1    |
| 1-6     | 1E46FP.1-1                 | CAP             | 1    | 1-35    | 1E48FP.5-3               | PISTON RING    | 1    | 1-64    | GB70.1+GB93+GB97.1 M5X10 | BOLT            | 2    |
| 1-7     | 1E40F-3A.8-2               | SPRING          | 1    | 1-36    | 1E48FP-10                | GASKET         | 1    | 1-65    | 1E48FP-3                 | GASKET          | 1    |
| 1-8     | BPMR7A                     | PLUG            | 1    | 1-37    | 1E48FP-E.2-2             | BACK CRANKCASE | 1    | 1-66    | GB70.1+GB93+GB97.1 M5X20 | BOLT            | 4    |
| 1-9     | 1E48FP-E-1                 | CYLINDER A      | 1    | 1-38    | 1E40FP-3Z-19             | RATCHET        | 1    | 1-67    | 1E48FP-E.5               | COVER           | 1    |
| 1-10    | GB6171 M10X1.25            | NUT             | 1    | 1-39    | 1E40FP-3Z-16             | NUT            | 1    | 1-68    | 1E48FP-E.6               | COVER           | 1    |
| 1-11    | GB93 10                    | WASHER          | 1    | 1-40    | GB67 M5X12               | SCREW          | 1    |         |                          |                 |      |
| 1-12    | GB97.1 10                  | WASHER          | 2    | 1-41    | 1E40FP-3Z.4-4            | WASHER         | 1    |         |                          |                 |      |
| 1-13    | 1E46FP.1.1                 | ROTOR           | 1    | 1-42    | 1E40FP-3Z.4-5            | GUIDE SLICE    | 1    |         |                          |                 |      |
| 1-14    | 1E40FP-3Z-11               | SEAL            | 2    | 1-43    | GB860 8                  | WASHER         | 1    |         |                          |                 |      |
| 1-15    | GB70.1+GB93+GB848 M5X35    | BOLT            | 4    | 1-44    | 1E40FP-3Z.4-8            | START WHEEL    | 1    |         |                          |                 |      |
| 1-16    | 1E48FP-E.2-1               | FRONT CRANKCASE | 1    | 1-45    | 1E40FP-3Z.4-9            | ROPE           | 1    |         |                          |                 |      |
| 1-17    | GB119 B4X10                | PIN             | 2    | 1-46    | 1E40FP-3Z.4-6            | PULLEY         | 1    |         |                          |                 |      |
| 1-18    | GB/T276 6302/P5            | BEARING         | 2    | 1-47    | 1E40FP-3Z.4-7            | SPRING         | 1    |         |                          |                 |      |
| 1-19    | 1E48FP.6-2                 | GASKET          | 1    | 1-48    | 1E40FP-3Z.4-1            | CASE           | 1    |         |                          |                 |      |
| 1-20    | 1E46FP.1.1                 | ROTOR           | 1    | 1-49    | 1E40FP-3Z.4-2            | HANDLE         | 1    |         |                          |                 |      |
| 1-21    | GB818 M4X6                 | BOLT            | 2    | 1-50    | 1E40FP-3Z.4-10           | PACK           | 1    |         |                          |                 |      |
| 1-22    | GB93 4                     | WASHER          | 2    | 1-51    | GB70.1+GB93+GB97.1 M5X50 | BOLT           | 1    |         |                          |                 |      |
| 1-23    | GB70.1+GB93+GB97.1 M5X20   | BOLT            | 2    | 1-52    | 1E48FP-8                 | BAFFLE         | 1    |         |                          |                 |      |
| 1-24    | 1E46FP.1-3                 | GROMMET         | 1    | 1-53    | 1E48FP.3-2               | CHOKER         | 1    |         |                          |                 |      |
| 1-25    | GB70.1+GB93+GB97.1 M5X20   | BOLT            | 1    | 1-54    | 1E48FP.3-1               | COVER          | 1    |         |                          |                 |      |
| 1-26    | 1E46FP-2                   | RETAINER        | 1    | 1-55    | 1E48FP-7                 | SEALING GASKET | 1    |         |                          |                 |      |
| 1-27    | 1E48FP.4.1                 | STOP WIRE       | 1    | 1-56    | 1E48FP.3-3               | HANDLE         | 1    |         |                          |                 |      |
| 1-28    | GB1099 3X13                | KEY             | 1    | 1-57    | GB845 ST2.9X8.5          | SCREW          | 1    |         |                          |                 |      |
| 1-29    | 1E48FP-E.1.1               | CRANKSHAFT      | 1    | 1-58    | 1E48FP-E.4               | CARBURATOR     | 1    |         |                          |                 |      |

Appendix List of Attached  
Fig.2(EB-650A-E)



| Appendix List of Attached Fig.2(EB-650A-E) |                  |                           |      |          |                |                                |       |          |                 |                                |      |
|--------------------------------------------|------------------|---------------------------|------|----------|----------------|--------------------------------|-------|----------|-----------------|--------------------------------|------|
| Ser. NO.                                   | Part NO.         | Part Name                 | Qty. | Ser. NO. | Part NO.       | Part Name                      | Qty.  | Ser. NO. | Part NO.        | Part Name                      | Qty. |
| 1                                          | 3WF-20.9-2       | 自攻螺钉M5×16<br>SCREW M5×16  | 4    | 19       | EB-415.4.2-2   | 胶塞<br>VITTA PLUG               | 1     | 37       | EB-650.7-3      | PIPE                           | 1    |
| 2                                          | 3W-30-2          | 防护罩<br>PROTECTION         | 1    | 20       | EB-415.4.2-4   | 回油管<br>FUEL TUBE               | 100mm | 38       | EB-650-E.5-1    | 吹风管三<br>PIPE                   | 1    |
| 3                                          | GB70.1+GB93+GB97 | 螺钉组合件M6×30<br>SCREW M6×30 | 6    | 21       | CG420.1.3.2-2  | 进油管<br>FUEL TUBE               | 270mm | 39       | EB-650.7.2-1(A) | 手把组合<br>HANDLE                 | 1    |
| 4                                          | 3W-30.2-1        | 前半蜗壳组合<br>VOLUTE CASE     | 1    | 22       | P40.12.2-3A    | 燃油过滤器<br>FILTER                | 1     | 40       | GB/T5783        | 螺栓 M6×45<br>BOLT M6×45         | 1    |
| 5                                          | EB-650.2.1       | 叶轮组合<br>IMPELLER ASSEM    | 1    | 23       | EB-500-E.4-1   | 油箱<br>FUEL TANK                | 1     | 41       | GB/T96.1        | 垫圈Φ6<br>WASHER Φ6              | 1    |
| 6                                          | GB70.1+GB93+GB97 | 螺钉组合件M5×35<br>SCREW M5×35 | 4    | 24       | 1E32FL.6.2-1   | 油箱盖<br>FUEL TANK LID           | 1     | 42       | GB/T62          | 螺母M6<br>NUT M6                 | 1    |
| 7                                          | 3W-30.2-2        | 后半蜗壳组合<br>VOLUTE CASE     | 1    | 25       | CG420.1.3.1    | 密封垫<br>SEALING WASHER          | 1     | 43       | GB/T846         | 自攻螺钉ST2.9×13<br>SCREW ST2.9×13 | 1    |
| 8                                          | GB/T818          | 自攻螺钉M5×16<br>SCREW M5×16  | 12   | 26       | EB-415.4.1.1-1 | 进气嘴<br>AIRVALVE                | 1     | 44       | BL750.3-9       | 按钮<br>PUSH BUTTON              | 1    |
| 9                                          | GB/T818          | 螺钉M5×55<br>SCREW M5×55    | 2    | 27       | 1E32FL.6.2-2   | 油箱内盖<br>LID                    | 1     | 45       | BL750.3-7       | 弹簧<br>SPRING                   | 1    |
| 10                                         | EB-500-E-3       | 防护网<br>PROTECT NET        | 1    | 28       | 1E32FL.6.2-3   | LID                            | 1     | 46       | CG330B-3E.2.1.2 | 左半操纵盒<br>LEFT MANIPULATOR      | 1    |
| 11                                         | 3WF-2.6B-2       | 塑料卡子<br>BACK CLIP         | 12   | 29       | 1E32FL.6.2-4   | CHAIN                          | 1     | 47       | BL750.3-8       | PIN                            | 1    |
| 12                                         | 3W-11.3          | 减振柱<br>SUPPORT            | 1    | 30       | 250×4.5        | 线扎<br>LINE                     | 2     | 48       | BL750.3-2       | SPRING                         | 1    |
| 13                                         | EB-500-E-2       | 机架<br>FRAME               | 1    | 31       | 3WF-16.3.1     | 风机弯头组合<br>FAN JOINT ASSEM      | 1     | 49       | BL750.3-3       | 手柄<br>HANDLE                   | 1    |
| 14                                         | GB/T96.1         | 垫圈 Φ6<br>WASHER Φ6        | 5    | 32       | 3F-30.18-2     | 橡胶套<br>RUBBER PLUG             | 1     | 50       | BL750.3-4       | 油门手柄<br>HANDLE                 | 1    |
| 15                                         | GB/T6177         | 螺母 M6<br>NUT M6           | 3    | 33       | JB8870         | 喉箍(Φ78~Φ101)<br>CLIP(Φ78~Φ101) | 1     | 51       | BL750.3-1       | 长扭簧<br>LONG SPRING             | 1    |
| 16                                         | EB-500-E-1       | 背垫<br>BACK MAT            | 1    | 34       | EB-650.7-2     | HOSE                           | 1     | 52       | CG330B-3E.2.1-1 | 右半操纵盒<br>RIGHT MANIPULATOR     | 1    |
| 17                                         | EB-500-E.3       | 背带<br>BAND                | 2    | 35       | JB8870         | 喉箍(Φ59~Φ82)<br>CLIP(Φ59~Φ82)   | 1     | 53       | GB/T845         | 螺钉ST2.9×18<br>SCREW ST2.9×18   | 3    |
| 18                                         | GB70+GB93        | 螺钉组合件M6×16<br>SCREW M6×16 | 2    | 36       | EB-650.7.1     | 吹风管一<br>PIPE                   | 1     | 54       | GB/T70.1        | 螺钉M5×30<br>SCREW M5×30         | 1    |

| Appendix List of Attached Fig.2(EB-650A-E) |                  |                                 |      |          |               |                                      |      |          |          |           |      |
|--------------------------------------------|------------------|---------------------------------|------|----------|---------------|--------------------------------------|------|----------|----------|-----------|------|
| Ser. NO.                                   | Part NO.         | Part Name                       | Qty. | Ser. NO. | Part NO.      | Part Name                            | Qty. | Ser. NO. | Part NO. | Part Name | Qty. |
| 55                                         | BC36. 3. 1       | 停车开关<br>STOP SWITCH             | 1    | 73       | JB8870        | 喉箍Φ46-Φ70<br>CLIPΦ46-Φ70             | 2    |          |          |           |      |
| 56                                         | 3WF-16. 3. 2. 2  | 油门绳<br>FUEL THROTTLE            | 1    | 74       | EB-800-E. 2-5 | 引风管<br>PIPE                          | 1    |          |          |           |      |
| 57                                         | 3WF-16. 3. 2-1   | 护套管<br>TUBE                     | 1    | 75       | EB-650A-E-2   | 化油器内罩壳<br>CLEANER INSIDE COVER       | 1    |          |          |           |      |
| 58                                         | GB/T889. 1       | 螺母M5<br>NUT M5                  | 1    | 76       | XSS46-2. 2-5  | 自攻螺钉M5×20<br>SCREW M5×20             | 3    |          |          |           |      |
| 59                                         | GB/T70. 1        | 螺钉M5×10<br>SCREW M5×10          | 1    | 77       | EB-800-E. 2-8 | 挡油板<br>BAFFLE                        | 1    |          |          |           |      |
| 60                                         | GB/T6170         | 螺母M5<br>NUT M5                  | 1    | 78       | GB/T 845      | 自攻螺钉ST4. 8×9. 5<br>SCREW ST4. 8×9. 5 | 2    |          |          |           |      |
| 61                                         | 3F-30. 17        | 减振柱<br>SUPPORT                  | 2    | 79       | EB-800-E. 2-9 | 化油器罩壳垫<br>GASKET                     | 1    |          |          |           |      |
| 62                                         | EB-650A-E-1      | 风机堵头<br>LID                     | 1    |          |               |                                      |      |          |          |           |      |
| 63                                         | GB/T845          | 自攻螺钉ST4. 8×8<br>SCREW ST4. 8×8  | 4    |          |               |                                      |      |          |          |           |      |
| 64                                         | XSS46-2. 2-5     | 螺钉M5×20<br>SCREW M5×20          | 2    |          |               |                                      |      |          |          |           |      |
| 65                                         | EB-800-E. 2. 1-2 | 空滤器外罩二<br>CLEANER OUTSIDE COVER | 1    |          |               |                                      |      |          |          |           |      |
| 66                                         | EB-800-E. 2-1    | 海绵滤芯<br>FILTER                  | 1    |          |               |                                      |      |          |          |           |      |
| 67                                         | EB-800-E. 2-2    | 滤芯支架<br>FILTER BRACKET          | 1    |          |               |                                      |      |          |          |           |      |
| 68                                         | EB-800-E. 2-3    | 纸滤芯<br>FILTER                   | 1    |          |               |                                      |      |          |          |           |      |
| 69                                         | GB70+GB93+GB97   | 螺钉组合件M6×25<br>SCREW M6×25       | 4    |          |               |                                      |      |          |          |           |      |
| 70                                         | EB-800-E. 2. 2   | 空滤器内罩组合<br>CLEANER INSIDE COVER | 1    |          |               |                                      |      |          |          |           |      |
| 71                                         | EB-650. 5. 3     | 锁紧螺钉<br>SCREW                   | 2    |          |               |                                      |      |          |          |           |      |
| 72                                         | EB-800-E. 2. 1-1 | 空滤器外罩一<br>CLEANER OUTSIDE COVER | 1    |          |               |                                      |      |          |          |           |      |