

CERUTI

www.ceruticenter.it

ESPLOSO


Soffiatore

EB420E



KASEI


Fig. 1 ENGINE GROUP



NO.	Part NO.	Part Name	Qty.
Engine Group			
1	1E40FP-3Z.5B	MAGNETO	1
2	1E40FP-3Z.5A	WINDING	1
3	1E40FP-3Z.5	IGNITION COIL COMP.	1
4	1E40FP-3Z.5B	MAGNETO ROTOR COMP.	1
5	1E34F-2E-EMC.1	SPRING	1
6	1E34F-2E-EMC.1	CAP	1
7	1E40FP-3Z-16	NUT M10×1	2
8	GB/T859 10	WASHER	1
9	GB/T848 10	WASHER	1
10	GBT70+GB/93+GB97	SCREW M4×20	2
11	1E34F.1.2A	KNOB BOLT	2
12	EB-420-E.1.1-1	OUTSIDE COVER	1
13	EB-420-E.1.1-2	FILTER NET	1
14	GB70.1+GB93+GB97	SCREW M5×55	2
15	P40.1-3	BAFFLE	1
16	EB-420-E.1.1.1	INSIDE COVER	1
17	1E40F-2E.1B	CARBURETOR	1
18	EB-500-E.1-5	GASKET	1
19	GB70.1+GB93+GB97	SCREW M5×25	2
20	EB-420-E.1.2	INSULATOR	1
21	EB-420-E.1-2	GASKET	1
22	EB-420-E.1-4	AIR DEFLECTOR	1
23	1E40FP-3Z-14	FRONT CRANKCASE	1
24	1E40FP-3Z-13	SEALING WASHER	1
25	1E40FP-3Z-11	SEAL	2
26	GB/T276 6202/P6	BEARING	2
27	1E40FP-3Z.3A.1	CRANKSHAFT	1
28	1E40FP-3Z.3.2	BEARING	1
29	1E40FP-3Z.3-4	RING	2
30	1E40FP-3Z.3-3	PISTON PIN	1

31	1E40FP-3Z.3-2	PISTON	1
32	1E40FP-3Z.3-5	PISTON RING	2
33	1E40FP-3Z.3-1	KEY	1
34	1E40FP-3Z-12	BACK CRANKCASE	1
35	1E40FP-3Z-6	SEALING WASHER	1
36	EB-420-E.1-1	CYLINDER	1
37	GB/T70.1 M5×20	SCREW	4
38	GB/T818 M5×8	SCREW	1
39	GB/T70.1 M5×30	SCREW	4
40	EB-420-E.1-3	GASKET	1
41	EB-420-E.1.3	MUFFLER	1
42	EB-420-E.1.4	SHIELD	1
43	GB70.1+GB97	SCREW M6×70-12.9	2
44	GB70.1+GB93+GB97	SCREW M5×12	1
45	BPMR7A	SPARK PLUG	1
46	GB70.1+GB93+GB97	SCREW M5×16	4
47	1E40FP-3Z.4	STARTER	1
48	1E40FP-3Z.4-1	CASE	1
49	1E40FP-3Z.4-7	SPRING	1
50	1E40FP-3Z.4-6	PULLEY	1
51	1E40FP-3Z.4-8	PULLEY	1
52	GB67 M5×12	SCREW	1
53	GB/T860 8	Washer	1
54	1E40FP-3Z.4-5	GUIDE SLICE	1
55	1E40FP-3Z.4-4	WASHER	1
56	1E40FP-3Z.4-2	HANDLE	1
57	1E40FP-3Z.4-9	ROPE	1
58	1E40FP-3Z-19	RATCHET	1
59	GB/T97.1 10	WASHER	1
60	1E40FP-3Z-20(A)	FIXITY	1
61	GB/T119.1	Pin 4h8×10	2

Fig. 2 BLOWER GROUP



Blower Group			
1	3WF-20.9-2	Screw 5×16	12
2	EB-420-E-1	Engine Cover	1
3	GB70.1+GB93+GB97	Screw M6×30	4
4	EB-520-E.3-1	Bracket	2
5	EB-420-E.2.2	Volute Case	1
6	EB-420-E.2.1	Fan Comp.	1
7	GB70.1+GB93+GB97	Screw M6×35-10.9	4
8	EB-420-E.2-1	Volute Cover	1
9	XSS46.2-2	Screw 5×20	8
10	EB-650.9	Belt	1
11	EB-650.8	Damper	1
12	EB-420-E-4	Cover	1
13	EB-420-E-3	Net	1
14	EB-420-E-2	Frame	1
15	GB96	Washer 5	1
16	GB6177	Nut M5	1
17	EB-420-E.5	Pad	1
18	3WF-14-13	Clip	4
19	EB-650-10	Shaft	2
20	EB-500-E.3A	Band Assy	2
21	HB33.2.2	Cap Assy	1
22	.1E32FL.6.2-1	.Cap	1
23	.CG420.1.3.1-2	.Packing	1
24	.EB-415.4.1.1-1	.Holder	1
25	.1E32FL.6.2-2	.Lid	1
26	.1E32FL.6.2-3	.Lid	1
27	.1E32FL.6.2-4	.Stoper	1
28	EB-420-E.3-1A	Fule Tank	1
29	P40.12.2-3A	Filter	1
30	EB-415.4.2-4	Fule Tube	100mm

31	CG420.1.3.2-2	Fule Tube	210mm
32	EB-415.4.2-2	Rubber stopper	1
33	JB8870(φ78-φ90)	Clamp	1
34	3WF-3.5	Support	2
35	GB96	Washer 6	3
36	GB6177	Nut M6	2
37	EB-420-E.4-1	Hose	1
38	EB-420-E.2-2	Elbow	1
39	GB818	Screw M5×65	2
40	GB845	Screw ST4.2×13	3
41	3WF-2.6B-2	Clip	6
42	GB70.1+GB93+GB848	Screw M6×16	2
43	JB8870(φ59-φ82)	Clamp	1
44	EB-650.7.1	Swivel Joint	1
45	EB-650.7-3	Straight Pipe	1
46	EB-420-E.4-2	End Pipe	1
47	GB70.1	Screw M6×45	1
48	Handle	EB-650.7.2A	1
49	GB62	Nut M6	1
50	EB-420-E-CZHZZ	Handle Assy	1
51	.BC36.3.1	.Stop Switch	1
52	.EB-420-E.4.1.4	.Cable	1
53	.3WF-16.3.2-1	.Tube	1
54	.EB-420-E.4.1-2	.Lever	1
55	.EB-420-E.4.1.1	.Handle case	1
56	.EB-420-E.4.1-3	.Rotating block	1
57	.EB-420-E.4.1-1	.Block	1
58	.EB-420-E.4.1.3	.Trigger	1
59	.EB-420-E.4.1.2	.Handle cover	1
60	.GB/T845	.Screw St2.9×19	1
61	.EB-420-E.4.1-4	.Spring	1
62	.GB/T845	.Screw St4.8×16	1
63	.GB97	.Washer 5	1
6	.GB70.1	.Screw M5×30	1