







Esploso ricambi decespugliatore
Exploded view Brush cutter

AGPZ-451

[01 MAIN PIPE / DRIVE SHAFT / FLEXIBLE SHAFT]

Ref.	Part Number	Description	Q'ty
1	T2413-340A	JOINT ASSY	1
2	T6214-009A	COVER, BEARING	1
3	T803A0627	BEARING, BALL (827ZZ)	1
4	T190D0520	BOLT (M5x20, SW)	1
5	T4923-005A	BOLT (M5x25)	1
6	T461L0500	WASHER, SPRING (M5)	1
7	T199D0510	BOLT (M5x10, SW-WS)	1
8	T3313-310A	PIPE, MAIN	1
9	T5233-014B	METAL BUSH ASSY	5
10	T4113-099A	SHAFT, DRIVE	1
11	T5453-012A	THROTTLE LEVER ASSY	1
12	T4025-148A	FLEXIBLE ASSY	1
13	T3057-039A	OUTER FLEXIBLE	1
14	T3225-014A	FLEXIBLE SHAFT, INNER	1
15	T6214-010A	COVER, JOINT	1
16	T5552-003A	O-RING (P-18)	1
17	T6314-001A	CAP	1
18	T6314-006A	CAP	1
19	T6111-250A	LOOP HANDLE ASSY (φ 26)	1
20	T6111-027A	LOOP HANDLE	1
21	T6111-026A	BARRIER, LOOP HANDLE	1
22,23	T8474-005A	SCREW & NUT SET (M5)	1
24	T6112-500A	SAFETY GUARD ASSY (φ 26)	1
25	T6112-048A	GUARD, SAFETY	1
26	T3427-044A	STAY, SAFETY GUARD	1
27	T197D0616	BOLT (M6x16, SW-W)	4



[02 GEAR CASE]

Ref.	Part Number	Description	Q'ty
A	T2411-550A	GEAR CASE ASSY	1
1	T2411-036A	GEAR CASE COMP.	1
2	T2411-004A	CASE, GEAR	1
3	T4111-011A	SHAFT, GEAR	1
4	T4141-006A	PINION	1
5	T4141-007A	GEAR	1
6	T605A6201	BEARING, BALL (6201DDU)	1
7	T801A0629	BEARING, BALL (629)	1
8	T801A6000	BEARING, BALL (6000)	1
9	T802A6000	BEARING, BALL (6000Z)	1
10	T481J3200	RING, STOP (R-32)	1
11	T481J2600	RING, STOP (R-26)	1
12	T480J1000	RING, STOP (S-10)	1
13	T110B0608	BOLT-HB	1
14	T197B0630	BOLT (M6x30, SW-W)	1
15	T197B0512	BOLT (M5x12, SW-W)	1
16	T223D0508	SCRW (M5x8, SW)	3
17	T3425-042A	HOLDER, UPPER	1
18	T3425-034A	HOLDER, LOWER	1
19	T350D1000	NUT (M10)	1
20	T3421-018A	DISC	1
21	T3426-004E	COVER	1
22	T3424-058A	BRACKET, SAFETY GUARD	1




Esploso ricambi decespugliatore
Exploded view Brush cutter

AGPZ-451



[03 CLUTCH HOUSING ASSY]

Ref.	Part Number	Description	Q'ty
1	T2421-200B	CLUTCH HOUSING ASSY	1
2	T2421-014C	HOUSING, CLUTCH	1
3	T3413-016C	DRUM, CLUTCH	1
4	T803A6202	BEARING, BALL (6202ZZ)	1
5	T4941-003B	PIN, STOPPER	1
6	T5313-005B	COIL SPRING	1
7	T482S0500	CLIP	1
8	T480J1500	RING, STOP (S-15)	1
9	T481J3500	RING, STOP (R-35)	1
10	T197D0630	BOLT (M6x30, SW-W)	4




[04 FRAME]

Ref.	Part Number	Description	Q'ty
1	T3331-242A	FRAME	1
2	T8315-011A	BACKPACK	1



[05 ENGINE MOUNT]

Ref.	Part Number	Description	Q'ty
1	T3424-050A	TURN BRACKET	1
2	T6212-028B	DAMPER	3
3	T346D0600	NUT, FLANGE (M6)	8
4	T120S0612	CAP BOLT (M6x12)	1
5	T4117-018A	SHAFT, ENGINE MOUNT	1
6	#818	WASHER, FLAT (M10)	2
7	530312DA	ENGINE PLATE	1
8	T461L1000	WASHER, SPRING (M10)	1
9	T314D1000	NUT (M10)	2
10	T466L1000	WASHER	1
11	T120S0630	CAP BOLT (M6x30)	1
12	T197D0616	BOLT (M6x16, SW-W)	4



[06 TOOL SET]

Ref.	Part Number	Description	Q'ty
1	T8447-001A	TOOL SET	1
2	T8443-002A	SPANNER (8X10)	1
3	T8444-002A	PIN, STOPPER (4.5mmX100L)	1
4	T8442-003A	SOCKET WRENCH (17X19)	1
5	T8441-001A	DRIVER	1
6	T8446-001A	CONVEX BAND	2

Rif.	Codice	Descrizione
[01 ASTA - TUBO - FLESSIBILE]		
8	RDZT3313-310A	ALBERO + BRONZINE
10	RDZT4113-099A	ALBERO DI TRASMISSIONE
11	RDZT5453-012A	IMPUGNATURA ACC. CPL.
12	RDZT4025-148A	FLESSIBILE CPL.
14	RDZT3225-014A	FLESSIBILE INTERNO
24	RDZT6112-500A	SAFETY GUARD ASSY (Ø26)
[02 COPPIA CONICA]		
A	RDZT2411-550A	COPPIA CONICA CPL.
3	RDZT4111-011A	ALBERO INTERNO
4	RDZT4141-006A	PIGNONE INGRANAGGIO
5	RDZT4141-007A	INGRANAGGIO
17	RDZT3425-042A	GHIERA SUPERIORE
18	RDZT3425-034A	GHIERA INFERIORE
[03 CAMPANA FRIZIONE]		
1	RDZT2421-200B	CAMPANA FRIZIONE CPL.
3	RDZT3413-016C	CAMPANA FRIZIONE
[04 SCHIENALE]		
2	RDZT6315-011A	BRETELLA
[05 SUPPORTO MOTORE]		
2	RDZT6212-028B	ANTIVIBRANTE

Ref.	Code	Description
[01 MAIN PIPE - DRIVE SHAFT - FLEXIBLE SHAFT]		
8	RDZT3313-310A	PIPE ASSY
10	RDZT4113-099A	SHAFT
11	RDZT5453-012A	THROTTLE LEVER ASSY
12	RDZT4025-148A	FLEXIBLE ASSY
14	RDZT3225-014A	INNER FLEXIBLE
24	RDZT6112-500A	SAFETY GUARD ASSY (Ø26)
[02 GEAR CASE]		
A	RDZT2411-550A	GEAR BOX ASSY
3	RDZT4111-011A	SHAFT
4	RDZT4141-006A	DRIVING GEAR
5	RDZT4141-007A	GEAR
17	RDZT3425-042A	UPPER FLANGE
18	RDZT3425-034A	LOWER FLANGE
[03 CLUTCH HOUSING ASSY]		
1	RDZT2421-200B	CLUTCH HOUSING ASSY
3	RDZT3413-016C	CLUTCH DRUM
[04 FRAME]		
2	RDZT6315-011A	HARNESS
[05 ENGINE MOUNT]		
2	RDZT6212-028B	ANTIVIBRATION