


MODEL 312003x50A - TS01942


REPAIR PARTS CHASSIS & HOOD



MODEL 312003x50A

REPAIR PARTS CHASSIS & HOOD

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Seat	690567	29	Lens, Right	1001545E245
2	Cap, Push On	028x23	30	Housing, Right Headlamp	1001543
3	Spring	094057	31	Screw	26x270
4	Screw	26x229	32	Screw	26x238
5	Bolt, Wing	1001054	33	Bearing, Steering	1001491
6	Washer	017x47 Z	34	Dash	1001584E717
7	Bolt, Shoulder	009x56	35	Screw	26x201
8	Support, Seat	094154E701	36	Panel, Access	093007E717
9	Rod, Pivot	094156 Z	37	Support, Dash	095318E717
10	Bracket, Pivot	094153E700	38	Bracket, Rear Hanger	1001270E701
11	Bolt	001x45	39	Support, Left Grille	094085E700
12	Nut	015x89	40	Axle, Hanger	094007E700
13	Bolt, Shoulder	009x55	41	Support, Right Grille	094084E700
14	Washer	094155 Z	42	Bolt, Shoulder	009x58
15	Spring	164x31	43	Frame, Right	1001268E701
16	Screw	26x249	44	Frame, Left	1001269E701
17	Screw	26x263	45	Container, Battery	690424
18	Spring	164x30	46	Plate, Hitch	1001002E701
19	Deck, Seat	1001558E245	47	Panel, Rear	690434E701
20	Nut	15x123	48	Support, Battery	690482E701
21	Plate, Index	094151E701	49	Screw	26x277
22	Screw	009x47	50	Nut	015x81
23	Mat, Left	1001583	51	Nut	15x124
24	Mat, Right	1001580	53	Insert, Grille	1001541
25	Hood	1001538E245	54	Screw	26x259
26	Grille	1001531E700	55	Fastener, Panel	193x1
27	Lens, Left	1001546	70	Holder, Cup	1001542
28	Housing, Left Headlamp	1001544E245	—	Instruction Book & Parts List	F-030711L




MODEL 312003x50A

REPAIR PARTS MOTION DRIVE

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Bolt, Shoulder	009x39	32	Pin, Hair	0031x6
2	Nut, Hex	015x89	33	Washer	017x38
3	Arm, Idler	690173 Z	34	Spacer	690369
4	Rod, Clutch	094041 Z	35	Bolt	06x105
5	Nut	015x79	36	Transaxle **	—
6	Washer	17x102	37	Nut	015x88
7	Grip	092697	38	Key, Woodruff	020697
8	Pin, Cotter	030x20	39	Bolt	01x155
9	Lever, Shift	094043 Z	40	Bracket, Transaxle	094008E701
10	Washer	017x47 Z	41	Pulley	690409
11	Link, Shift	094044 Z	42	Bracket, Transaxle Support	094433E700
12	Nut, Adjuster	021920	43	E-Ring	0011x7
13	Grip	091079	44	Pulley, Drive	095094
14	Rod, Parking Brake	1001245 Z	45	Key, Square	021553
15	Nut, Adjuster	094815	46	Washer	17x160
16	Bracket, Shift Pivot	1001303 Z	47	Spacer, Transaxle	690554 Z
17	Screw	26x249	48	Stem, Valve	024373
18	Nut	015x84	49	Tire *	
19	Mount, Stud Spring	094042 Z	—	Tube	407049
20	Bolt, Shoulder	009x54	50	Wheel & Tire Assembly	690376–601
21	Spring, Extension	165x116	51	Washer	17x195
22	Bracket, Right Shifter	1001302E701	52	Ring Retainer	0011x3
23	Frame, Right	1001268E700	53	Hub Cap	094618
24	Bolt, Carriage	002x53	54	Guide, Belt	093349
25	Frame, Left	1001269E700	55	Pin, Hair	0031x4
26	Latch, Parking Brake	094045 Z	56	Spring, Extension	165x116
27	Pedal	021544	57	Spring, Extension	165x92
28	Lever, Brake/Clutch	94038E700	58	Screw	26x216
29	Nut	015x98	59	Washer	17x148
30	Belt, Motion Drive	037x87	60	Screw	26x267
31	Yoke, Shift	094031 Z	61	Washer	17x169

* When you order a tire, make sure to give the brand name of the tire so that the tread pattern on the tire will match.

** For information on Replacement Parts see the Central Parts Distributor in your area.




MODEL 312003x50A

REPAIR PARTS STEERING

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Wheel, Steering	095184	23	Washer	17x104
2	Post, Steering	690625	24	Washer	017x53 Z
3	Insert, Steering Wheel	711325	25	Nut, Flange	015x84
4	Bearing	094124	26	Axle Assembly	1001460E701
5	Nut, Flange	15x111	27	Drag Link, Left	095329E701
6	Bolt, Shoulder	009x57	28	Spindle Assembly, Right	1001298E701
7	Gear, Pinion	690183	29	Drag Link, Right	095328E701
8	Ring, Snap	011x25	30	Screw	26x249
9	Gear, Sector	094121	31	Bearing, Wheel	091334
10	Bearing	094123	32	Stem, Valve	024373
11	Bolt	001x84	33	Tire *	
12	Plate, Steering	1001121E701	—	Tube	407046
13	Plate, Engine	094006E700	34	Wheel and Tire Assembly	690377–601
14	Nut, Flange	015x88	35	Washer	17x195
15	Nut, Flange	15x118	36	Washer	17x113
16	Bracket, Hanger	1001270E701	37	Washer	017x83
17	Axle, Hanger	094007E701	38	Hub Cap	094618
18	Bolt	01x146	39	Screw	26x267
19	Pin, Cotter	030x49	40	Bellows	054789
20	Bearing	690150	41	Bolt	0025x3
21	Spindle Assembly, Left	1001299E701	42	Washer	17x146
22	Bolt	01x111			

* When you order a tire, make sure to give the brand name of the tire so that the tread pattern on the tire will match.




MODEL 312003x50A

REPAIR PARTS MOWER HOUSING SUSPENSION

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Grip	092698	26	Bolt, Hex	001x74
2	Handle, PTO	094157 Z	27	Arm Assembly, Right Lift	690386E700
3	Pad, Switch	094022 Z	28	Arm, Right Lift	094180E700
4	Bolt	0025x3	29	Plate, Lift Arm	094030E700
5	Grip	092697	30	Pin	094067
6	Spring	166x40	31	Bracket, Rear Suspension	094055E701
7	Washer	17x103	32	Bushing, Lift Tube	094065
8	Handle, Lift	690533	33	Bolt, Shoulder	009x53
9	Lever, PTO	094017 Z	34	Bracket, Pivot	094015E700
10	Bolt, Shoulder	009x39	36	Washer	17x191
11	Pin, Cotter	030x20	37	Nut, Flange	015x84
12	Washer	017x57	38	Spring	165x117
13	Link, PTO	094004 Z	39	Nut, Flange	015x68
14	Nut, Flange	015x84	40	Bracket, PTO	094005E700
15	Screw	26x249	41	Hanger, Right Deck	094026E700
16	Spring	166x39	42	Hanger, Left Deck	094027E700
17	Bracket, PTO	094018E701	43	Rod, Hanger	094158 Z
18	Spring	165x116	44	Hanger, Front	690381E700
19	Crank, PTO	690394E701	45	Nut, Flange	015x89
20	Link, Lift	094053E701	46	Pin, Cotter	030x49
21	Link, Lift Handle	094028 Z	47	Pin, Threaded Shoulder	690382
22	Nut, Flange	15x118	48	Screw	26x49
23	Washer	17x57	49	Bolt, Hex	01x106
24	Pin, Hair	0031x4	50	Washer	017x38
25	Washer	017x91	51	Plate, Weight (4 Required)	690370E701

MODEL 312003x50A

REPAIR PARTS MOWER HOUSING




MODEL 312003x50A

REPAIR PARTS MOWER HOUSING

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Pulley	690432	29	Baffle	690399E700
2	Nut, Flange	015x84	30	Nut, Flange	015x89
3	Nut	15x140	31	Strap, Rubber	054695
4	Belt, Blade	037x74	32	Screw	01x139
5	Pulley, Idler	690387	33	Chute	690367
6	Mandrel	094129	34	Nut	015x79
7	Screw	0025x7	35	Spring, PTO	165x118
8	Guide, Belt	092424	36	Spring, Extension	165x140
9	Spacer	094130	37	Nut, Flange	015x84
10	Bracket, Rear Suspension	094055E701	38	Bracket, Front Deck	690380E700
11	Bolt, Shoulder	009x52	39	Pin, Threaded Shoulder	094067
12	Knob	094068	40	Washer	017x91
13	Washer	017x45	41	Pin, Hair	0031x4
14	Bolt, Shoulder	009x51	42	Hanger, Front	690381E700
15	Plate, Suspension	690379E700	43	Housing, Jackshaft	094305
16	Pad, Friction	094137	44	Fan, Assist	690359
17	Spring	166x43	45	Housing, Fan	1001237E701
18	Nut, Flange	015x79	46	Washer	017x37
19	Bracket, Rear Deck	690378E700	47	Bolt	001x71
20	Pin, Hanger	095194	48	Bolt	001x106
21	Link, Lift	094053	49	Nut	15x100
22	Nut	15x116	50	Washer	17x165
23	Bracket, Idler Arm	690427E700	51	Washer, Belleville	17x166
24	Assembly, Idler Arm & Pad	690647	52	Blade	690398E701
25	Screw	26x249	53	Adapter, Blade	1001035
26	Bolt, Shoulder	009x39	54	Bolt	01x121
27	Bolt, Carriage	002x64	55	Nut, Flange	015x98
28	Housing, Blade	690530E700	1-54	Blade Housing, Complete	776110

MODEL 312003x50A

REPAIR PARTS ENGINE MOUNT




MODEL 312003x50A

REPAIR PARTS ENGINE MOUNT

Key No.	Description	Part No.
1	Fuel Cap	092317
2	Fuel Tank	690280
3	Hose Clamp (Incl'd w/Key 2)	095197
4	Fuel Line (Incl'd w/Key 2) (Must cut to Length)	7601033
5	Hose Clamp	095197
6	Screw	26x201
7	Plate, Engine	094006E700
8	Throttle Control	092371
9	Engine*	———
10	Bolt, Engine Mount	0025x7
11	Stack Pulley Assembly	690439 Z
12	Lockwasher	019x35
13	Bolt, Hex	01x140
14	Washer	17x170
15	Screw	26x249
16	Gasket	091309
17	Muffler	091271
18	Deflector, Muffler	1001350
19	Screw	26x208
20	Bolt, Hex	01x134
21	Guide, Belt	093349
22	Nut, Flange	015x79 Z
23	Guide, Belt	094066
24	Shield, Heat	1001595 Z
26	Screw	26x253
27	Screw	26x263
28	Shield, Heat	091277

* Parts are available from an engine Authorized Service Center. See "Engines, Gasoline" or "Gasoline Engines" in the yellow pages of the telephone directory.




MODEL 312003x50A

REPAIR PARTS ELECTRICAL SYSTEM

Key No.	Description	Part No.
1	Harness, Light Wire	250x92
	Socket, Light	092372
	Bulb, Light	090084
2	Harness, Chassis Wire	250x118
3	Switch, Ignition	092377
	Key, Ignition	020729
	Nut, Hex	091489
	Cap, Ignition	091488
4	Switch, Limit	1001575
5	Fuse	302031
	Holder, Fuse	407078
6	Solenoid	094613
	Screw, Mounting	26x229
	Locknut	15x116
7	Cable, Battery Ground	024x32
	Screw, Ground Cable	26x213
8	Battery	021075
	Bolt, Carriage	002x82
	Wingnut	014x79
	Boot, Battery –Positive	690604
9	Harness, Seat Switch Wire	250x119
10	Switch, Seat Sensor	094159
11	Cable	024x31
12	Switch, Bag Sensor	690106

MODEL 312003x50A

REPAIR PARTS GRASS BAGGER



MODEL 312003x50A

REPAIR PARTS GRASS BAGGER

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Tube, Top	690404	16	Washer	17x185
2	Bolt	001x94	17	Latch, Spring	690402
3	Nut	15x116	18	Pan, Rear	690362E701
4	Strut, Bag	690433	19	Bolt, Carriage	002x53
5	Nut, Flange	015x79	20	Bracket, Bagger Mounting	690355E700
6	Fastener, Panel	0193x1	21	Screw	01x127
7	Seal, Bag (Right End)	690491	22	Plate, Hitch	1001000E701
8	Seal, Bag (Center)	690492	23	Bracket, Lower Mounting	1001001E701
9	Seal, Bag (Left End)	690493	24	Plate, Hitch	1001002E701
10	Hinge	690356E700	25	Nut	015x41
11	Screw	26x249	26	Pin, Latch	054563
12	Assembly, Bag Frame	690403	27	Bolt, Carriage	002x39
13	Bracket, Switch	690400E700	28	Tube, Connecting	690368
14	Bolt, Carriage	002x82	29	Grommet, Extension Tube	690429
15	Nut, Flange	015x89	30	Bag, Grass	690438